


**CR5000**  
QUICK START GUIDE



**code**  
ADVANCED BARCODE READERS



[www.codecorp.com](http://www.codecorp.com)



User Manual  
Manuel d'Utilisateur  
Manual de Usuário  
Manual do Usuário  
Benutzerhandbuch  
유저-매뉴얼  
用戶手冊  
사용자 매뉴얼




Configuration Guide  
Guide de Configuration  
Guide de Configuration  
Guía de Configuración  
Guia de Configuração  
Programmierhandbuch  
設定コード表  
配置指南  
설정 가이드




[YouTube.com/codecorporation](https://www.youtube.com/codecorporation)

**Included  
if Ordered**


Inclus si commendé    Incluido si así lo ordena    Incluídos se ordenou  
Inbegriffen, wenn bestellt    注文時に追加    包括若订购    주문시 포함



USB Cable  
Câble d'USB  
Cable USB  
Cabo USB  
USB-Kabel  
USB 케이블  
USB 线缆  
USB 케이블




RS232 Cable  
Câble de RS232  
Cable rs232  
Cabo RS232  
RS232-Kabel  
RS232 케이블  
RS232 线缆  
RS232 케이블



Power Supply  
Alimentation électrique  
Fuente de alimentación  
Fonte de alimentação  
Netzteil  
ACアダプタ  
充电电源  
Power Supply



## Set Up

Installation Instalación Instalação  
Einrichten 設定 设置 셋업



## Scanning

Lecture Escaneo Leitura Scannen  
스캔 扫描 扫描 스키닝



## Power On

Allumer Encender Ligar Einschalten  
電源オン 电源开启 Power on

